First in LEDs...The solid state warning light leader.™

FLASH PATTERN GUIDE
GALAXY / GALAXY ELITE
Version 060104

The following shows the available Galaxy Elite flash patterns as of June 1, 2004. Next to the LED Flash Patterns shows the default Warning combination. For example, "Warning 1" + "Warning 2" activates pattern #3 from the factory. Remember, however, that any combination of "Warning" inputs can be configured to any of these flash patterns. Refer to the Galaxy Installation Guide for guidelines on how to Configure the Galaxy's flash patterns.

LED Flash Patterns	Default Warning
1. Rear, End Caps, WW, 1 Hz	1
2. Rear, End Caps +1, WW, 1 Hz	2
3. Rear, End Caps +1, WW 2, 1 Hz	1+2
4. Rear, Inside-Out, 1 Hz	3
5. Rear, Inside-Out, 1 Hz, Chicago	1+3
6. End Caps, WW, 1 Hz	2+3
7. End Caps +1, WW, 1 Hz	1+2+3
8. End Caps +1, WW 2, 1 Hz	4
9. End Caps +2, WW, 1 Hz	1+4
10. End Caps +3, WW, 1 Hz (Split Modules)	2+4
11. Front, End Caps +2, WW, 1 Hz	1+2+4
12. Front, End Caps +3, WW, 1 Hz (Split Modules)	3+4
13. End Caps, WW, 2 Hz	1+3+4
14. Full Bar, Chicago	2+3+4
15. Full Bar, Chicago (Split Modules)	1+2+3+4
16. Front, WW, Chicago 2 (Split Modules)	5
17. Front, WW, Chicago	1+5
18. Full Bar, On / Off Flash	2+5
19. Full Bar, Alternating Pairs, 1 Hz	1+2+5
20. Full Bar, Alternating Pairs Chicago	3+5
21. Full Bar, Inside-Out	1+3+5
22. Full Bar, Inside-Out, Chicago	2+3+5
23. Rear, Center Segment(s), 9 Hz	1+2+3+5
24. California Version of #6	4+5
25. California Version of #7	1+4+5
26. California Version of #8	2+4+5
27. California Version of #9	1+2+4+5
28. California Version of #10	3+4+5
29. California Version of #11	1+3+4+5
30. California Version of #12	
31. California Version of #13	
32. California Version of #14	
33. California Version of #15	

LED Flash Patterns continued

34. California Version of #16
35. California Version of #17
36. California Version of #18
37. California Version of #19
38. California Version of #20
39. California Version of #21
40. California Version of #22
41. Hostage Light
42. End Caps, Cruise Lights, Day
43. End Caps, Cruise Lights, Night
44. Revolver – Counter Clockwise
45. Revolver - Clockwise

Directional Flash Patterns

1. All Segments with Tracer - Default
2. All Segments - Traditional
3. Inner Segments with Tracer
4. Tracer + End Caps

Alley Light Flash Patterns

1. Off - Default
2. Steady-On
3. 1 Hz. Wig-Wag
4. ½ Hz. Wig-Wag

Take-Down Flash Patterns

1. Off - Default
2. Steady-On
3. 1 Hz. Wig-Wag
4. ½ Hz. Wig-Wag

DISCLAIMER: 911EP® reserves the right to make changes to this document and the products it describes without notice. 911EP® assumes no responsibility for editorial errors or omissions herein, nor does it make any commitment to update the information contained within.